Continue

Hello Tecnobits! ☺ Ready to reboot and give your Technicolor router a shake? 📶 Don't miss our quick and easy guide to reset Technicolor router. Let's go for technology! 📶 – Step by Step ➡ How to reset Technicolor router Disconnect Technicolor router from the outlet and wait at at least 30 seconds before plugging it back in. Finds the reset button on the back of the router. It is usually marked as “Reset” or “Reboot.” When the router is off, press and keep Pressed the reset button for at least 15 seconds. Once you release the button, waiting for the router to fully reboot and all the lights are on and stable. Make sure reschedule any custom settings you previously made on the router once it has been reset. + Information ➡ 1. Why do you need to reset your Technicolor router? Resetting the Technicolor router is a common measure to fix connectivity, configuration or security issues. Additionally, it can be useful if you have forgotten the password for your Wi-Fi network or if you are experiencing problems accessing the internet. Exclusive content - Click Here How to convert a router into a wifi adapter2. What is the method to reset Technicolor router to factory settings? To reset a Technicolor router to its factory settings, follow these steps: Find the reset button on the rear panel of the router. It is usually labeled “Reset” or “Reboot.” Press and hold the reset button for at least 10 seconds. Wait for the router to reboot automatically. This process may take several minutes. 3. What is the difference between resetting and restarting Technicolor router? Restart the router simply turn the device off and on, while reset it to factory settings erases all saved settings and resets the router to its original state. 4. What should I do before resetting my Technicolor router? Make a backup copy of the current settings if you want to keep them. You can do this by accessing the router's management interface and looking for the backup or export settings option. Write down the current configuration, especially the internet connection and Wi-Fi network settings information, so you can reconfigure the router after the reset. Exclusive content - Click Here How to Access Verizon Router Settings5. How long does it take to reset Technicolor router? The Technicolor router reset process may take several minutes. During this time, the router will reboot and reset to its factory settings. It is important not to interrupt this process. 6. What should I do after resetting the Technicolor router? After resetting the Technicolor router to its factory settings, you will need to perform the following steps: Reconfigure your internet connection. Enter the details provided by your internet service provider into the router's management interface. Reestablish the Wi-Fi network. Set up a new network name and password for your wireless network. Restore the backup of the configuration, if you previously made a backup. 7. Can I reset the Technicolor router without an internet connection? Yes, you can reset the Technicolor router without an internet connection. Resetting the router is done locally, it does not require internet access to do so. 8. How can I check if the Technicolor router reset was successful? After resetting the Technicolor router, you can verify the success of the process by doing the following: Connect a device to the Wi-Fi network using the new password you set after the reset. Access the administration interface of the router using the default IP address and default credentials. Exclusive content - Click Here How to install VPN on Spectrum router9. Are there risks when resetting the Technicolor router? Resetting the Technicolor router to its factory settings will erase all saved settings y will reset the Wi-Fi network and management credentials to default values. Therefore, it is important make a backup important settings before carrying out this process. 10. How can I get additional assistance if I'm having trouble resetting my Technicolor router? If you encounter difficulties resetting your Technicolor router, you can seek help in the manufacturer's official documentation either contact Technicolor customer service for additional assistance with the reset process. Until next time, Tecnobits! Always remember that if you need to reset the Technicolor router, you just have to reset Technicolor router. See you! I am Sebastián Vidal, a computer engineer passionate about technology and DIY. Furthermore, I am the creator of tecnobits.com, where I share tutorials to make technology more accessible and understandable for everyone. Info updated May 26, 2025 The majority of Technicolor routers have a default username of admin, a default password of admin, and the default IP address of 192.168.0.1. These Technicolor credentials are needed when doing a login to the Technicolor router's web interface to change any settings. Since some of the models don't follow the standards, you can see those in the table below. Below the table are also instructions on what to do incase you forget your Technicolor router password, need to reset your Technicolor router to its factory default password, or the password reset doesn't work. Tip: Press ctrl+f (or cmd+f on Mac) to quickly search for your model number. Technicolor default Password List (Valid May 2025) Instructions and common questions Forgot your Technicolor router password? Have you changed the username and/or password of your Technicolor router and forgotten what you changed it to? Don't worry: all Technicolor routers come with a default factory set password that you can revert to by following the instructions below. Reset Technicolor router to default password If you decide to revert your Technicolor router to it's factory defaults, you should do the 30-30-30 reset as follows: When your Technicolor router is powered on, press and hold the reset button for 30 seconds. While still holding the reset button pressed, unplug the power of the router and hold the reset button for another 30 seconds While still holding the reset button down, turn on the power to the unit again and hold for another 30 seconds. Your Technicolor router should now be reset to its brand new factory settings, Check the table to see what those are (Most likely admin/admin). If the factory reset didn't work, check out the Technicolor 30 30 30 factory reset guide . Important: Remember to change the default username and password to increase the security of your router after the factory reset, as the default passwords are available all over the web (like here). I still can't access my Technicolor router with the default password Make sure that you have followed the reset instructions correctly as the Technicolor routers should always rever to their factory default settings when reset. Otherwise, there is always the risk that your router is damaged and might need to be repaired or replaced. ×Sorry to interruptCSS Error Here is a list of all the username and password combinations that we are aware of for Technicolor routers. Technicolor Model Username Password 7210D blank admin 7230s blank admin AGHP admin admin C2000T admin located on bottom of router C2100T admin printed on router CGA0101 admin admin CGA0101 admin password CGA0111 blank admin CGA2121 admin technicolor CGA4131COM cusadmin highspeed CGA4131TCH blank blank CGA4233EU blank blank CGA4233TCH3 custadmin cga4233 CGA4234 admin blank CGA4234DGW admin blank CGA4234VGW admin blank CGA4234VGW-TCH admin blank CGM4140COM admin password CGM4231MDC provided by ISP provided by ISP CGM4331COM admin password CGM4331COM admin printed on router CGM4981COM admin password CobraXh admin printed on router DGA0122 admin printed on router DGA4132 admin admin DGA4135 admin printed on router DJA0230TLS admin admin DJA0231 admin Telstra DPC3848V cusadmin unknown DPC3939 admin password EPC3928S admin blank EPC3940ADL admin password FGA2233PTN admin printed on router MediaAccess DGA2232 admin admin MediaAccess DGA2232 admin printed on router MediaAccess DGA4131FWB root root MediaAccess TG1100 FastWeb fastweb blank MediaAccess TG588v v2 admin access key printed on router MediaAccess TG589vac v2 admin printed on router MediaAccess TG589vn v3 admin admin MediaAccess TG589vn v3 Administrator access key printed on router MediaAccess TG589vn v3 Administrator blank MediaAccess TG788v v3 admin printed on router MediaAccess TG789vac v2 admin admin MediaAccess TG789vac v2 admin printed on router MediaAccess TG789vac v2 iiNet admin admin MediaAccess TGiiNet-1 admin admin TC4400 admin bEn2o#US9s TC4400 user password TC4400 user Techni1789# TC7110 blank admin TC7200 admin admin TC7200 blank admin TC7200-U admin admin TC7200.20 admin admin TC7200.d1l blank admin TC7200.d2p admin admin TC7200K admin password TC7200v2 admin admin TC7210 blank admin TC7210.dNZ blank admin TC7210.Z ziggo draadloos TC7230 admin admin TC7300 admin 4135279 TC8305C admin password TC8305E admin password TC8715D admin password TC8717T admin password TD5130 admin admin TD5130 v3 admin admin TD5136v2 admin admin TD5336 admin admin TG389ac admin admin TG582n admin SerialNumber TG582n Administrator blank TG582n Administrator printed on router TG582n TELMEX same as default WPA key, printed on router TG582n PRO admin printed on router TG582n v2 MediaAccess access key on label access key on label TG582n v2 MediaAccess blank blank TG582n-O2 Administrator blank TG587n admin admin TG587n Administrator blank TG587n Administrator printed on label TG589vn v2 admin admin TG589vn v3 Administrator Printed on router TG784n Administrator blank or access key on label TG784n Administrator blank or the access key printed on label TG784n v3 Administrator printed on router TG784n v3 MaxisBB printed on router TG784n v3 meo meo TG788Avn STC admin admin TG788vn Administrator blank TG788vn Administrator blank TG788vn Administrator printed on router label TG788vn v2 MediaAccess admin admin TG789Bvn Admin unknown TG789Bvn Expert unknown TG789Bvn User unknown TG789vac MediaAccess admin admin TG789vac MediaAccess user user TG789vac v2 MediaAccess iiNet admin blank TG789vac v3 admin printed on router TG789vn admin blank TG789vn Administrator Blank or Printed on Routers Label TG789vn v3 vini vini TG797nv3 admin password TG799 admin printed on router TG799vac admin telstra TG799vacXTREAM admin printed on router TG799vn v2 admin password TG799vn v2 Administrator printed on router TG799vn v3 Administrator printed on router TG800vac admin admin TG852n admin 1234 These are the factory default passwords for Technicolor routers. If you have changed the password in your router, then you need to use the new password that you have set. This list does not include Technicolor WiFi passwords and will not help you connect to your WiFi network. Secure Your Passwords with NordPass Have you considered using a password manager to protect your accounts? For most users, a dedicated password manager like NordPass is a much simpler and more secure choice than relying on memory or browser-saved passwords. We use and recommend NordPass because it not only stores and encrypts all of your passwords, but also helps generate strong, unique passwords for every account. With NordPass, you can easily access your passwords across all devices, and the next-gen encryption ensures they remain safe, even from advanced cyber threats. When choosing a password manager, make sure it meets the following criteria: Your password manager should use zero-knowledge encryption, meaning only you have access to your data. Ensure that the provider has multi-factor authentication (MFA) options for added security. Look for automatic sync across all devices, so you always have access to your passwords. Verify that your provider offers secure password sharing for teams and families. Choose a password manager that is easy to use and makes organizing your accounts simple. This is the list of requirements we used when choosing a password manager. Many free or unsecure options may lack these vital features, so it’s essential to choose wisely. Based on zero-knowledge architecture and high encryption standards, NordPass meets all these requirements, giving you peace of mind for all your accounts. Once you've set up your NordPass account, you can securely access all your passwords on any device. It’s as simple as logging in, and your credentials are just a click away — no more resetting passwords or forgetting them again! Every time you click on one of our affiliate links, such as NordPass, we get a little kickback for introducing you to the service. Think of us as your password management wingman. How To Login to a Technicolor Router Technicolor routers have many settings that can be adjusted depending on your needs, such as WiFi network name, password, parental controls, and traffic prioritization. To access these settings, you need to login to your router's built-in firmware. To access your router's settings, you can use a standard web browser such as Chrome, Firefox, or Edge. It does not matter which web browser you use. In general, the steps to log in to a Technicolor router are the same no matter which model of router you have. Here's what you do: Find your router's internal IP address. Put that IP address in your web browser address bar. Login with your router's username and password. We cover all of these steps below, including how to find your router's IP address and a list of all known default Technicolor passwords. Find Your Technicolor Router's IP Address To login to your router, you need to know it's IP address. All Technicolor routers have 2 IP addresses, but we are only interested in your router's internal IP address. Internal IP address - used for local configuration from inside your network. External IP address - used by your friends and coworkers to connect to you from the internet side of things. Since we are configuring your router from inside your network, we need to know the internal IP address. From here on, for simplicity, we will refer to your router's internal IP address as it's IP address. Just remember that whenever we say IP address, we mean internal IP address. You can find your router's IP address any of the following ways: The simplest way to find your Technicolor IP address is to try all known default IP addresses. Here are all the known default Technicolor IP addresses. Technicolor Model IP Address 7210D 192.168.0.1 7230s 192.168.0.1 7300b 192.168.0.1 AGHP 192.168.1.1 C2000T 192.168.0.1 C2100T 192.168.0.1 C2100T 192.168.1.1 CGA0101 192.168.0.1 CGA0111 192.168.0.1 CGA2121 192.168.0.1 CGA4131COM 10.1.10.1 CGA4131COM 192.168.1.1 CGA4131TCH 192.168.0.1 CGA4233EU 192.168.0.1 CGA4233TCH3 192.168.0.1 CGA4234 192.168.0.1 CGA4234DGW 192.168.0.1 CGA4234VGW 192.168.0.1 CGA4234VGW-TCH 192.168.0.1 CGM4140COM 10.0.0.1 CGM4140COM 192.168.0.1 CGM4140COM 192.168.1.1 CGM4231MDC 192.168.0.1 CGM4331COM 10.0.0.1 CGM4331COM 192.168.0.1 CGM4981COM 10.0.0.1 CobraXh 192.168.0.1 CobraXh DGA0122 192.168.1.1 DGA4132 192.168.1.1 DGA4135 192.168.1.1 DJA0230TLS 192.168.0.1 DJA0231 192.168.0.1 DPC3848V 192.168.0.1 DPC3848VE 192.168.0.1 DPC3939 10.0.0.1 EPC3928S 192.168.0.1 EPC3940ADL 192.168.0.1 FGA2233PTN 192.168.1.1 MediaAccess DGA2232 192.168.1.1 MediaAccess DGA4131FWB 192.168.1.254 MediaAccess DGA4131FWB MediaAccess TG1100 FastWeb 192.168.1.254 MediaAccess TG588v v2 192.168.1.1 MediaAccess TG589vac v2 192.168.1.1 MediaAccess TG589vn v3 192.168.1.1 MediaAccess TG589vn v3 192.168.1.254 MediaAccess TG589vn v3 MediaAccess TG788v v3 10.0.0.138 MediaAccess TG788v v3 192.168.1.1 MediaAccess TG789vac v2 10.1.1.1 MediaAccess TG789vac v2 192.168.1.1 MediaAccess TG789vac v2 192.168.1.254 MediaAccess TG789vac v2 iiNet 10.1.1.1 MediaAccess TG789vac v2 Internode 10.1.1.1 MediaAccess TGiiNet-1 10.1.1.1 TC4400 192.168.100.1 TC7110 192.168.0.1 TC7200 192.168.0.1 TC7200-U 192.168.0.1 TC7200.20 192.168.0.1 TC7200.d1l 192.168.0.1 TC7200.d2p 92.168.0.1 TC7200K 192.168.0.1 TC7200v2 192.168.0.1 TC7210 172.22.22.1 TC7210.dNZ 192.168.0.1 TC7210.Z 192.168.178.1 TC7230 192.168.87.1 TC7300 192.168.0.1 TC8305C 10.0.0.1 TC8305E 10.0.0.1 TC8715D 192.168.0.1 TC8717T 192.168.0.1 TD5130 192.168.1.1 TD5130 v3 192.168.1.1 TD5136v2 192.168.1.1 TD5336 192.168.1.1 TG389ac 192.168.5.1 TG582n 192.168.1.254 TG582n TG582n PRO 192.168.1.254 TG582n PRO TG582n v2 MediaAccess 192.168.1.1 TG582n v2 MediaAccess 192.168.1.254 TG582n-O2 192.168.1.254 TG587n 10.0.0.138 TG587n 192.168.1.254 TG589vn 192.168.1.1 TG589vn v2 192.168.1.254 TG589vn v3 192.168.1.254 TG784n 192.168.1.254 TG784n v3 192.168.1.254 TG788Avn STC 192.168.1.1 TG788vn 192.168.1.254 TG788vn v2 MediaAccess 192.168.1.1 TG789Bvn 192.168.1.1 TG789vac 192.168.10.1 TG789vac MediaAccess 10.0.0.1 TG789vac MediaAccess 192.168.1.254 TG789vac v2 MediaAccess iiNet 10.1.1.1 TG789vac v3 10.1.1.1 TG789vn 192.168.1.1 TG789vn 192.168.1.254 TG789vn v3 192.168.1.254 TG797nv3 10.0.0.138 TG799 10.0.0.138 TG799vac 10.0.0.138 TG799vacXTREAM 192.168.10.1 TG799vn v2 192.168.1.1 TG799vn v2 192.168.1.254 TG799vn v3 192.168.1.1 TG800vac 10.0.0.138 TG852n 192.168.1.1 TG852n 192.168.1.254 Start with the first IP address in the list and try to login to your router with it. To login to your router, follow the steps outlined below. If the IP address you picked does not work, then try a different one. It is harmless to try all the listed IP addresses since the only thing that we are doing here is trying to access the firmware settings of your router. How To Login To a Technicolor Router Once you have an IP address that you want to try, it's time to use your web browser to log in. Find the address bar in your web browser. It looks something like this: Type your router's IP address into the address bar and press the Enter key on your keyboard. You should see either your router's home screen or a screen asking for your username and password. If you do not see anything or you get an error that says This site can't be reached then the IP address that you are trying is wrong. Go back to the list of IP addresses above and try a different one. If you try all the IP addresses above and still cannot log in, then you can follow our How to Find Your Router's IP Address guide. Technicolor Default Username and Password You need to know your Technicolor username and password to login to your router. If you are not sure what your router's username and password are, then your router may still be set to the factory defaults. If your password does not work, you can try all the default Technicolor passwords and see if any of them work. Keep trying them all until you get logged in. Technicolor Model Username Password 7210D blank admin 7230s blank admin AGHP admin admin C2000T admin located on bottom of router C2100T admin printed on router CGA0101 admin admin CGA0101 admin password CGA0111 blank admin CGA2121 admin technicolor CGA4131COM cusadmin highspeed CGA4131TCH blank blank CGA4233EU blank blank CGA4233TCH3 custadmin cga4233 CGA4234 admin blank CGA4234DGW admin blank CGA4234VGW admin blank CGA4234VGW-TCH admin blank CGM4140COM admin password CGM4231MDC provided by ISP provided by ISP CGM4331COM admin password CGM4331COM admin printed on router CGM4981COM admin password CobraXh admin printed on router DGA0122 admin printed on router DGA4132 admin admin DGA4135 admin printed on router DJA0230TLS admin admin DJA0231 admin Telstra DPC3848V cusadmin unknown DPC3939 admin password EPC3928S admin blank EPC3940ADL admin password FGA2233PTN admin printed on router MediaAccess DGA2232 admin admin MediaAccess DGA2232 admin printed on router MediaAccess DGA4131FWB root root MediaAccess TG1100 FastWeb fastweb blank MediaAccess TG588v v2 admin access key printed on router MediaAccess TG589vac v2 admin printed on router MediaAccess TG589vn v3 admin admin MediaAccess TG589vn v3 Administrator access key printed on router MediaAccess TG589vn v3 Administrator blank MediaAccess TG788v v3 admin printed on router MediaAccess TG789vac v2 admin admin MediaAccess TG789vac v2 admin printed on router MediaAccess TG789vac v2 iiNet admin admin MediaAccess TGiiNet-1 admin admin TC4400 admin bEn2o#US9s TC4400 user password TC4400 user Techni1789# TC7110 blank admin TC7200 admin admin TC7200 blank admin TC7200-U admin admin TC7200.20 admin admin TC7200.d1l blank admin TC7200.d2p admin admin TC7200K admin password TC7200v2 admin admin TC7210 blank admin TC7210.dNZ blank admin TC7210.Z ziggo draadloos TC7230 admin admin TC7300 admin 4135279 TC8305C admin password TC8305E admin password TC8715D admin password TC8717T admin password TD5130 admin admin TD5130 v3 admin admin TD5136v2 admin admin TD5336 admin admin TG389ac admin admin TG582n admin SerialNumber TG582n Administrator blank TG582n Administrator printed on router TG582n TELMEX same as default WPA key, printed on router TG582n PRO admin printed on router TG582n v2 MediaAccess access key on label access key on label TG582n v2 MediaAccess blank blank TG582n-O2 Administrator blank TG587n admin admin TG587n Administrator blank TG587n Administrator printed on label TG589vn v2 admin admin TG589vn v3 Administrator Printed on router TG784n Administrator blank or access key on label TG784n Administrator blank or the access key printed on label TG784n v3 Administrator printed on router TG784n v3 MaxisBB printed on router TG784n v3 meo meo TG788Avn STC admin admin TG788vn Administrator blank TG788vn Administrator blank TG788vn Administrator printed on router label TG788vn v2 MediaAccess admin admin TG789Bvn Admin unknown TG789Bvn Expert unknown TG789Bvn User unknown TG789vac MediaAccess admin admin TG789vac MediaAccess user user TG789vac v2 MediaAccess iiNet admin blank TG789vac v3 admin printed on router TG789vn admin blank TG789vn Administrator Blank or Printed on Routers Label TG789vn v3 vini vini TG797nv3 admin password TG799 admin printed on router TG799vac admin telstra TG799vacXTREAM admin printed on router TG799vn v2 admin password TG799vn v2 Administrator printed on router TG799vn v3 Administrator printed on router TG800vac admin admin TG852n admin 1234 Some routers lock you out after trying too many incorrect passwords. If this happens, then just let it timeout for a minute and try again. Forgot Technicolor Password If you have changed your Technicolor password and forgot it, then you have the following choices: Resetting your router can be a very time-consuming process and may require contacting your ISP to get connected to the internet again. Please do not reset your router until you have tried every other way of getting logged in. Don't forget to sign up for NordPass's promo deal before it's gone. You might notice that most of our site doesn't have ads on it. This is because we use partnerships with companies like NordPass to keep the site running. Thank you for supporting us by using our referral links. If your Internet Service Provider (ISP) has installed a Technicolor router at your home or office, you should learn how to access its web interface to customize its default settings. This Technicolor Router login guide will help you with that in the simplest possible manner. In this post, I will guide you on how to log in to the admin interface of your Technicolor Router within minutes. So, you can tweak some settings and make them perform better. Not only this, but you can also secure your network connection. Technicolor Router Login Technicolor routers are very popular worldwide. It offers a residential gateway that comes with two ports and two voice lines that is suitable for any home or office user. These routers also claim to work in a manner conserving energy and serve cost-effective features. That’s why a lot of Internet Service Providers choose to install these for their networks. If you are also using a Technicolor router model, you should learn how to log in to its admin panel (web interface). The admin panel is a settings interface from where you can change or edit any default setting that the Technicolor router is using as default. This can help you to make the router perform even better. Here is the complete guide for your Technicolor router that will help you to learn its login procedure, default router IP, username, password, reset procedure, and more. Things to Do Before Proceeding Before proceeding to try logging in, you have to be sure about certain things. This will help you to eliminate any upcoming issues while logging in. Make sure the router is turned on. The router is connected to the device either via a wireless or wired connection. Your device could be a Windows PC, Mac, Android smartphone, or iPhone. You have installed the latest version of a browser like Chrome, Firefox, Edge, or Safari. The connection between the Technicolor router and device is stable (Preferably use an ethernet cable to connect). Once you have met these requirements, continue with the steps mentioned below. Step-1: Find the Default IP of your Technicolor Router Every router has a default IP address that it uses to communicate with other devices on the network. This IP is assigned by the manufacturers in the factory. Technicolor makes have used 4 different IP addresses for their routers. Here is the percentage of that shared by various models: It is essential to find out what is the default IP for your Technicolor router. You can find it on the sticker/label present on the router, or on the user manual. If you are unable to find it this way, there is one more available. Follow these steps to find the default IP of your router: Connect your Windows PC to the router either via wired or wireless connection. Press the Windows+X key to trigger the power user menu on the PC. Click on ‘Command Prompt (Admin)’ from the menu. In the Command Prompt window, type ipconfig and press ‘Enter’ on the keyboard. Let the command run, and you will find the default router IP present next to “Default Gateway” as shown above. You can now use this IP address to proceed with the next steps. Step-2: Access the Technicolor Router Login Page Now that you know the default IP for your Technicolor router, you have to use it to access the router login page. To do that, open a web browser, enter the default IP (in my case it was 192.168.0.1, so I will use it) in the URL bar, and hit ‘Enter’ on the keyboard. Alternatively, you can also use any of these links: 10.0.0.1 – click here. 192.168.0.1 – click here. 192.168.1.1 – click here. 192.168.1.254 – click here. After the page loads, you will see the Technicolor router login page on the screen. Step-3: Log in using Technicolor Router Username & Password Next, you have to enter the router username and password in their given fields on the login page. If you don’t know the credentials, you can use the default ones listed below. Try entering ‘admin’ in the username field, and ‘admin’ in the password field, and click on the ‘Sign in’ button. If it shows an incorrect username or password prompt, try using other default usernames and passwords (preferably for your model), or just reset the router to default credentials. After that, you will be able to log in and access the Technicolor admin panel. Default Technicolor Router Login Username & Password You can try these default username and password combinations used by Technicolor routers. These will allow you to log in if you are still using the default credentials, and have not reset them. Remember that these passwords are case sensitive. Key Tip: Check the sticker or label present on the router, or the user manual to find the default router username and password. Formate Used here: Username & Password: admin & password (leave blank) & admin admin & admin (leave blank) & root (leave blank) & user Administrator & (leave blank) User & (leave blank) user & password (leave blank) & (leave blank) root & (leave blank) admin & 4135279 user & VTmgQapcEUaE If you don’t want to try all of these, I have listed the exact credentials for some Technicolor router models below. You can find the router model you are using and then use its default credentials. Default Router Username & Password for Technicolor Router Models Format Used: Model Default | Username | Default Password | Default IP address C1100T (CenturyLink) | admin | (leave blank) | 192.168.0.1 CGA0101 | admin | password | 192.168.0.1 CGA0112 | admin | password | 192.168.0.1 CGA4233 | (leave blank) | VTmgQapcEUaE | 192.168.100.1 DWA1230 | admin | (leave blank) | 192.168.1.1 TC4400 | user | password | 192.168.100.1 TC7200 | admin | admin | 192.168.0.1 TC7200 (Thomson) | admin | admin | 192.168.0.1 TC8305C | admin | password | 10.0.0.1 TD5130v1 | root | (leave blank) | 192.168.1.1 TD5136 v2 | user | (leave blank) | 192.168.1.1 TD5137 | admin | admin | 192.168.1.1 TG589vac v2 HP | admin | (leave blank) | 192.168.1.1 (Thomson) TG703 | ”blank” | ”blank” | 192.168.1.254 Steps to Reset Technicolor Router to Defaults If you can’t log in to the router control center even after using the correct default credentials, the only option left for you is to reset the router. Follow these steps to reset your Technicolor router: Locate the small ‘Reset’ button present in a hole at the back of your router. Press this button using a needle, pin, or another pointed object for around 15 seconds. Release the button when the indicator lights flash. The router will then turn off and then turn on itself. That’s it. You can now set it up like new using the default username and password. Final Words This was our Technicolor router login guide. You have now learned how to log in to its web interface to customize the default settings. You have also learned many more things about the router. All of this is enough to categorize yourself as a ‘power user.’ That’s all for this guide. I hope it helps you enough. Feel free to share your opinions using the comment box. Here is how to reset your Technicolor Router: To reset your device to factory settings: Get a thin pointed object such as a pin or a toothpick and insert it into the "Reset" buttonhole (as shown below) and hold down until all the LED's light up. Wait for the device to complete its reboot cycle and turn itself back on. ×Sorry to interruptCSS Error If your TC7200 router is not working as it should, dropping connections or not being responsive, you should first do a reset of the router to see if the problems persist. Other scenarios where you might want to reset your router is if you've forgotten the password or misconfigured it and can't get access anymore. Your can reset your Technicolor TC7200 in the following way(s): The 30-30-30 reset There are no specific instructions for this model yet, but you can always do the 30-30-30 reset as follows: When router is powered on, press the reset button and hold for 30 seconds. (Use a paper clip or something sharp) While holding the reset button pressed, unplug the power of the router and hold the reset button for 30 seconds While still holding the reset button down, turn on the power to the unit again and hold for another 30 seconds. This process usually works for resetting any router to it's factory setting. Note: It is worth reading more about how to reset routers with the 30 30 30 reset and what the risks and considerations are when resetting your router this way, instead of just rebooting it.