

Click to prove
you're human



Hold down MULTI & SPEAKER A/B buttons on the front panel of your receiver simultaneously with the power turned on for 3+ seconds. *Please note ALL settings will be reset to factory default. This includes all of your digital audio and video assignments as well as your radio stations and calibration settings. How do you reset Marantz?

SR5009/SR6009: Hold down the "TUNER PRESET CH -" and "DIMMER" buttons simultaneously for at least 3 seconds. SR5010/SR5011: Hold down the "TUNER PRESET CH +" and "STATUS" buttons simultaneously for at least 3 seconds. How do I reset my Marantz 7010? Various settings are reset to the factory default values. Make settings again, while simultaneously pressing GAME and A-DSX. Remove your fingers from the two buttons when "Initialized" appears on the display. How do I reset my Marantz receiver sr6006? Reset procedure: With the power off, press and hold the "DISPLAY" button, "ZONE SELECT" button, and "POWER" button simultaneously on the AVR for a few seconds until the AVR's display starts flashing at intervals of about 1 second. How do I reset my Marantz nr1501 receiver? While pressing the unit's MENU button, hold down the ▼ cursor button for at least 3 seconds. After "M-CLEAR" has appeared on the display, the STANDBY mode is established, the settings that were selected are initialized, and the default settings are restored. How do I reset my Marantz sr5012 receiver? Press and hold the main unit's DIMMER and TUNER PRESET CH - at the same time for at least 3 seconds. Remove your fingers from the two buttons when "Network Reset..." appears on the display. "Completed" is shown in the display when reset is complete. How do I reset my Marantz 1607? While simultaneously pressing M-DAX and ZONE2 SOURCE. Remove your fingers from the two buttons when "Initialized" appears on the display. How do you power cycle a Marantz receiver? Unplug the receiver, wait a while and then plug it back in. Just like unplugging and plugging in a PC, this will result in the processor being reset. How do I reset my Marantz cr612? Resetting network settings: Press INPUT on this unit to select "Internet Radio", "Music Servers" or "USB Music". Press and hold the BACK and. Remove your fingers from the two buttons when "Please wait" appears on the display. "Completed" is shown in the display when reset is complete. How do I factory reset my sr5009? Hold down MULTI & SPEAKER A/B buttons on the front panel of your receiver simultaneously with the power turned on for 3+ seconds. *Please note ALL settings will be reset to factory default. How do I reset my Marantz remote? Press and hold RC SETUP for more than 3 seconds. Indicator flashes twice on the remote control unit. To display "RESET" on the remote control unit and press ENTER, to display "ALL" on the remote control unit and press ENTER. How do I reset my Marantz SR 7011? Press and hold the main unit's BACK and ENTER at the same time for at least 3 seconds. Remove your fingers from the two buttons when "Network Reset..." appears on the display. "Completed" is shown in the display when reset is complete. How do I reset my Marantz 8801? 1 Turn off the power using ON/STANDBY. 2 Press ON/STANDBY while simultaneously pressing GAME and SLEEP. 3 Once the display starts flashing at intervals of about 1 second, release the two buttons. How do you troubleshoot a Marantz receiver? DR #23 - Marantz SR8002 Receiver Troubleshooting and Repair: How do I reset my Marantz nr1602? Reset procedure: With the power off, press and hold the "ENTER" button, "RETURN" button, and "POWER" button simultaneously on the AVR for a few seconds until the AVR's display starts flashing at intervals of about 1 second. How do I reset my Marantz nr1510? Press and hold the main unit's TUNER PRESET CH + and DIMMER at the same time for at least 3 seconds. Remove your fingers from the two buttons when "Network Reset..." appears on the display. "Completed" is shown in the display when reset is complete. How do you reset a Marantz SR 7013? Press and hold the main unit's BACK and ENTER at the same time for at least 3 seconds. Remove your fingers from the two buttons when "Network Reset..." appears on the display. "Completed" is shown in the display when reset is complete. How do you reset a Marantz sr6008? RESET MARANTZ /DENON How do you reset a Marantz sr6010? Various settings are reset to the factory default values. Make settings again, while simultaneously pressing M-DAX and ZONE2 SOURCE. Remove your fingers from the two buttons when "Initialized" appears on the display. How do you reset a Marantz sr5011? Various settings are reset to the factory default values. Make settings again, while simultaneously pressing M-DAX and ZONE2 SOURCE. Remove your fingers from the two buttons when "Initialized" appears on the display. How do I reset my Marantz sr6011? Also known as the factory reset. Turn ON the unit and simultaneously press the M-DAX and ZONE 2 SOURCE buttons. Wait until the display starts flashing in 1 second intervals, then release the two buttons. (3) Full Network reset. How do you reset a Marantz sr7005? Reset procedure: Turn off power using "ON/STANDBY" With the power off, press and hold the "SURROUND MODE" button, "AUTO" button, and "POWER" button simultaneously on the AVR for a few seconds until the AVR's display starts flashing at intervals of about 1 second. How do you reset a Marantz sr5010? While simultaneously pressing M-DAX and ZONE2 SOURCE. Remove your fingers from the two buttons when "Initialized" appears on the display. How do I reset my Marantz 7705? Press and hold the main unit's BACK and ENTER at the same time for at least 3 seconds. Remove your fingers from the two buttons when "Network Reset..." appears on the display. "Completed" is shown in the display when reset is complete. What year did the Marantz SR5009 come out? Specifications: BASIC Model: SR5009 Type: AV Receiver Country: USA Release Year: 2014 How do I pair my Marantz remote? Press and hold SET until the LEARN indicator blinks. Press input source select buttons to select the input source. Select the button to be learned. Press and hold the button that you want to register on the other remote control until "OK" is displayed on the Marantz remote control display. How do you reset a Marantz sr5001? Hold down the MULTI & ATT buttons on the front panel of your receiver simultaneously with the power of the unit turned on for 3+ seconds. *Please note ALL settings will be reset to factory default. Is Marantz remote programmable? Designed for easy-to-use, intuitive control, Marantz offers a complete line of programmable system remotes. Want to control an entire entertainment system at the touch of a button? With a Marantz programmable remote, it's no problem. There are a few ways to do this, but all newer AV and AVR models have a Factory Reset option listed in the menu (GUI) under General -> Factory Reset. From this menu, you can reset all saved settings or just your network settings. We highly recommend you save your settings to a USB drive before factory resetting the unit. To do that, place a supported USB drive into the unit's USB port. Then, access the menu (GUI) and select General -> Save/Load. This will save all altered settings including your Audyssey calibration. Once that's done, you can safely reset the unit. Another option to reset the unit's microprocessor would be to follow the push button reset procedure found in your model's owner's manual. Please see your owner's manual for this procedure as every model has a different push button procedure. What is the difference between a soft reset and a hard reset. A soft reset restores factory settings without erasing custom settings, while a hard reset completely powers down the amplifier, clearing its memory. Resetting your Marantz amplifier is a crucial step in troubleshooting and maintaining its optimal performance. Whether you're encountering glitches, experiencing distorted sound, or simply want to start fresh, a reset can rejuvenate your amplifier and restore its pristine audio quality. In this comprehensive guide, we'll delve into the various methods of resetting your Marantz amplifier, providing step-by-step instructions for each one. Methods of Resetting a Marantz Amplifier 1. Soft Reset (Factory Reset) A soft reset restores the amplifier to its factory default settings without erasing any custom settings or presets. Steps: 1. Power on the amplifier. 2. Locate the "Reset" button on the rear panel. 3. Press and hold the "Reset" button for 5-10 seconds. 4. The amplifier will turn off and then back on, indicating a successful reset. 2. Hard Reset (Power Cycle) A hard reset completely powers down the amplifier, clearing its memory and any temporary errors. Steps: 1. Unplug the amplifier from the power outlet. 2. Wait for 30 seconds. 3. Plug the amplifier back into the power outlet. 4. Power on the amplifier. 3. Master Reset (Firmware Update) A master reset involves updating the amplifier's firmware, which can resolve bugs and improve performance. Steps: Note: Firmware updates vary depending on the Marantz amplifier model. Refer to the user manual for specific instructions. 1. Download the latest firmware update from the Marantz website. 2. Connect a USB flash drive to your computer and copy the firmware file onto it. 3. Insert the USB flash drive into the amplifier's USB port. 4. Navigate to the "System" menu on the amplifier's display. 5. Select "Firmware Update" and follow the on-screen instructions. Troubleshooting Reset Issues Amplifier Not Resetting Ensure that you are pressing the "Reset" button long enough (5-10 seconds). Try a hard reset by power cycling the amplifier. Contact Marantz customer support if the issue persists. Custom Settings Lost Soft resets do not erase custom settings. Hard resets will clear all settings, including presets and volume levels. Firmware Update Error Verify that the USB flash drive is formatted in FAT32. Ensure that the firmware file is compatible with your amplifier model. Try a different USB flash drive. Additional Tips Before resetting your amplifier, consider backing up any important custom settings. Resetting an amplifier is a relatively simple process, but it can resolve a wide range of issues. If you encounter any difficulties or have questions, consult the amplifier's user manual or contact Marantz customer support. Recommendations: Reclaiming Audio Excellence Resetting your Marantz amplifier is a valuable technique for troubleshooting and maintaining its exceptional audio performance. By following the methods outlined in this guide, you can easily restore your amplifier to its factory settings, resolve glitches, and enjoy pristine sound quality for years to come. Remember, the ability to reset your amplifier empowers you to keep your audio system in optimal condition and maximize your listening experience. Frequently Discussed Topics Q: What is the difference between a soft reset and a hard reset? A: A soft reset restores factory settings without erasing custom settings, while a hard reset completely powers down the amplifier, clearing its memory. Q: Can I reset my Marantz amplifier using the remote control? A: No, the Marantz amplifier cannot be reset using the remote control. Q: How often should I reset my Marantz amplifier? A: Resetting your amplifier is not necessary unless you encounter issues or want to restore factory settings. Was this page helpful? Yes/No Thanks for your feedback! Before we dive into the reset procedures, let's understand why you might need to reset your Marantz amplifier in the first place. If your amplifier is having trouble connecting to other devices, like your TV, speakers, or network, a reset might help re-establish the connections. Software glitches, like your TV, speakers, or network, a reset might help re-establish the connections. Software glitches: Similar to any electronic device, Marantz amplifiers can experience software glitches. A reset can help clear these glitches and restore normal operation. Configuration errors: If you've made changes to your amplifier's settings and now things aren't working as intended, a reset can return the settings to their defaults. Troubleshooting: If you're experiencing an issue with your amplifier, a reset is often the first troubleshooting step to try. Different Methods for Resetting Your Marantz Amplifier Marantz offers a variety of amplifier models, and the reset procedure can vary slightly depending on the specific model. Here's how to use it: 1. Power off the amplifier: Make sure the amplifier is completely turned off. 2. Locate the Reset button: It's usually a small button, often labeled "Reset" or with a circular arrow symbol. 3. Press and hold the Reset button: Press and hold the button for several seconds, usually around 5-10 seconds. 4. Release the button: Once the reset process is complete, the amplifier will usually power on automatically. Method 2: Using the Remote Control Some Marantz amplifiers can be reset using the remote control. Here's how: 1. Power off the amplifier: Make sure the amplifier is completely turned off. 2. Locate the Reset button on the remote control: It may be labeled "Reset," "Factory Reset," or have a circular arrow symbol. 3. Press and hold the Reset button: Press and hold the button for several seconds, usually around 5-10 seconds. 4. Release the button: The amplifier will usually power on automatically after the reset is complete. Method 3: Using the On-Screen Menu If your Marantz amplifier has an on-screen menu, you can usually reset it through the menu settings. This method is often used for more advanced resets. 1. Power on the amplifier: Turn on the amplifier and navigate to the on-screen menu. 2. Locate the "Reset" or "Factory Reset" option: This option is typically found within the "Settings," "System," or "General" menu. 3. Select the "Reset" or "Factory Reset" option: Be sure to read any warnings or confirmations before proceeding. 4. Follow the on-screen instructions: The amplifier will guide you through the reset process. Before you reset your Marantz amplifier, it's essential to consider these factors: Backup your settings: If you've customized your amplifier's settings, such as speaker configurations, audio preferences, or network settings, consider backing them up before resetting. Understand the implications: Resetting your amplifier will restore it to its factory settings, meaning all your custom settings will be lost. Check your user manual: Always consult your Marantz amplifier's user manual for specific instructions and warnings related to resetting. Troubleshooting Tips After Resetting After resetting your Marantz amplifier, you may need to reconfigure some settings. Here are some common troubleshooting tips: Reconnect your devices: Make sure all your devices, including speakers, TV, and other connected components, are properly connected to the amplifier. Power cycle your devices: Turning off and on your amplifier and other connected devices can sometimes resolve connection issues. Verify your connections: Double-check that all cables are securely connected and that there are no loose connections. Update your firmware: Check for any available firmware updates for your Marantz amplifier, as these can address known issues and improve performance. While resetting your Marantz amplifier can often resolve issues, there are some situations where a reset may not be the solution. Hardware problems: If your amplifier has a hardware issue, such as a faulty component or a damaged connection, a reset won't fix the problem. External factors: Issues with your speakers, cables, or other connected devices can also cause problems, even after a reset. Software bugs: In rare cases, a software bug may persist even after a reset. You may need to contact Marantz support for assistance. Moving Beyond the Reset: Seeking Professional Help If you've tried resetting your Marantz amplifier and the problem persists, it's time to seek professional help. Contacting Marantz support or an authorized repair center is the best course of action. Resetting your Marantz amplifier can be a simple and effective way to address a range of issues, from audio glitches to software problems. By following these steps and understanding the implications, you can refresh your audio system and enjoy a seamless listening experience. What You Need to Learn Q: Will resetting my Marantz amplifier erase my saved presets? A: Yes, resetting your Marantz amplifier will erase all saved presets and restore the amplifier to its factory settings. Q: What if my Marantz amplifier doesn't have a Reset button? A: If your amplifier doesn't have a dedicated Reset button, you can try using the remote control or the on-screen menu, as described in the methods above. If those options aren't available, consult your user manual for specific instructions. Q: How often should I reset my Marantz amplifier? A: There's no set schedule for resetting your amplifier. Reset it only if you're experiencing issues or if you want to restore it to its default settings. Q: Can I reset my Marantz amplifier while it's connected to my network? A: Yes, you can usually reset your Marantz amplifier while it's connected to your network. However, it's a good practice to disconnect from the network if you're experiencing network-related issues. Q: What if I'm still having problems after resetting my amplifier? A: If you're still having problems after resetting your amplifier, contact Marantz support or an authorized repair center for further assistance. Did you know that 80% of Marantz AV Receiver users face sound quality problems? Many feel their surround sound is too centered on the middle speaker! If you're dealing with this dialogue, loud movie effects, or poor audio from your speakers, resetting your Marantz AV Receiver can help a lot. Resetting your Marantz AV Receiver can fix settings issues and improve your audio experience. This is true, even after recent updates. Experiencing problems with your receiver or audio presets? Knowing how to reset is essential for better sound. This guide will show you how to reset your receiver and solve common issues. You'll learn to enhance your listening experience. Key Takeaways Resetting can resolve persistent audio issues in your Marantz AV Receiver. 80% of users have reported issues mainly related to sound quality. Persistent problems often arise after software updates. Improper settings and low-quality speakers can worsen sound performance. A step-by-step reset guide can restore functionality and user satisfaction. Understanding your receiver's capabilities is key to long-term satisfaction. Understanding Common Issues with Marantz AV Receivers Marantz AV receivers are key for a better home theater experience. But, users often face problems that make their receiver stop working. Issues like no sound, wrong input settings, and connection problems are common. Knowing these issues helps you fix your receiver. Common Problems and Symptoms Many users struggle with their Marantz AV receivers. Some common problems include: No sound from specific channels Poor video quality Receiver entering protection mode due to short circuits in speaker wiring Audio delay issues that affect synchronization with video Frequent audio dropouts Overheating can also be a problem, caused by bad ventilation or loud settings. In many cases, a factory reset can fix these issues, even after trying other fixes. 2. Impact of Recent Updates Software updates can change how Marantz AV receivers work. Users of models like the AVR-XB500H and AV8805 have seen settings change after updates. These changes need to be set again manually, causing confusion. This is because of the complexity of managing connections and settings, often after the U17 update. 3. How to Troubleshoot Your Marantz AV Receiver Fixing your Marantz AV Receiver can solve many problems without a full reset. Here are steps to help you troubleshoot before resetting your receiver. Basic Troubleshooting Steps First, check the power plug and make sure it's plugged into a working outlet. If it won't turn on, check if the sleep timer or Auto Standby is the problem. 4. If it turns off by itself, adjusting these settings might fix it. If your remote control isn't working, try new batteries or remove any blocks between the remote and receiver. For display issues, look at the user manual for help. If there's no sound, check the connections, cable directions, and volume levels. Also, subwoofer problems might be due to power settings or wrong speaker setup, so check those too. 4. Temporary Fixes for U17 Update Problems For U17 update issues, double-check your network settings and reset them through the AVR setup menu. For audio problems in ZONE2/ZONE3 or with Bluetooth, see the manual for instructions. If you're getting sound interruptions, try adjusting the volume or turning off ECO Mode to avoid distortion, which can happen when streaming over Wi-Fi. 4. Issue Troubleshooting Steps Power Does Not Turn On Check power plug and settings Remote Control Issues Replace batteries and remove obstructions No Sound Check connections and volume levels Subwoofer Issues Verify power and configuration settings Sound Interruptions Adjust volume levels or turn off ECO Mode Knowing these troubleshooting steps can help fix many issues and keep your receiver working well. How to Reset Your Marantz AV Receiver Resetting your Marantz AV Receiver can fix many problems. To do it right, follow this easy guide. It shows you how to reset your receiver and what to watch out for. Step-by-Step Guide to Resetting First, turn off your Marantz AV Receiver and unplug it. Then, press and hold the Power button on the front. Plug it back in while holding the button. This starts the reset. Keep holding the Power button until the display shows it's rebooting. After it restarts, it will go back to its original settings. This can solve many common problems. Important Considerations Before Resetting Make sure to save any custom settings you have. A reset will delete them. Make sure your device is plugged into a steady power source during the reset. Resetting might not solve all issues. If problems continue, you might need to do more troubleshooting. By following these steps, you can reset your Marantz AV Receiver. This might fix ongoing problems. Just remember to be careful to avoid any issues after resetting. Conclusion Knowing how to reset your Marantz AV receiver can really help when you're dealing with problems. It's key to spot the signs of common issues, like those from updates or wrong settings. This way, you keep your audio system running at its best. By using the troubleshooting methods we talked about, you can fix problems and make your Marantz sound better. If simple fixes don't work, resetting your AV receiver is the next step. This helps solve more serious issues. Being proactive with your Marantz AV receiver can make your audio experience much better. Regular care and these tips help you get the most out of your home theater. This ensures your system keeps giving you top-notch sound quality. To reset your Marantz AV receiver, find the reset button on the back. Or, go to the setup menu. For a full reset, go to 'Settings' and choose 'Reset' or 'Factory Reset.' Follow the steps. This will clear all your custom settings. First, check all connections and the power supply. Try restarting or soft resetting the receiver. If it doesn't work, try a factory reset. Sound problems might come from wrong input settings or bad connections. Or, they could be from recent software updates. Check your input settings and speaker connections. Make sure everything is set right. Software updates, like the U17 update, might reset some settings to default. This can affect features like Audyssey. You might need to adjust your audio settings again for the best sound. Yes, for problems after the U17 update, try resetting specific settings. Check your network settings in the AVR setup menu. This might help temporarily. To do a factory reset, turn off the receiver and press and hold the reset button. Turn the power back on while holding the button. Follow any on-screen instructions. Remember, this will erase all your custom settings. Before resetting, save any settings you want to keep. Make sure your receiver is powered on and connected. This will help avoid problems during the reset. Start with simple checks like cable connections and input settings. If issues continue, try resetting specific settings or checking firmware. Look in the user manual for more troubleshooting tips. We are happy to announce the release of the new Marantz Remote App! The beautiful interface and intuitive layout offer a fun and simple way to control your Marantz network product. Adjust the basic functions of your Marantz product with power, volume, input and surround mode selection. Marantz disc player control is also available via RC-5 (Remote Control) connection. A customizable home screen allows you to tailor the look and function of the Marantz Remote App to suit your needs. A dedicated page now gives you full, easy to access control of your multi-room system. When used with new Marantz receivers, Internet Radio and Media Server navigation has been dramatically improved. Fast thumbnail browsing, library search and playlist creation make navigating your large digital media library easier than ever before. The Marantz Remote App takes your listening enjoyment to the next level. *Because Music Matters *Main feature- Single Page Multi Zone Control Screen for AV Receivers- Assignable Home Screen Shortcut Buttons- Fast Thumbnail Browsing for Network Music File Playback (*1)- Playlist management for Network Music File Playback (Create/Edit/Delete)- Frequency Direct FM Tuning- Fast Internet Radio Browsing (*1)- Volume Limit Setting- New Marantz Blu-ray Player Control when paired with 2012 or later AVR and Blu-ray Models (*2)- Photo Slideshow Transition Adjustment - AVR and Multi Zone Renaming Capability- Simple Home Screen Help Display- Multi-Language Support (English, French, German, Spanish, Dutch, Italian, Swedish, Japanese, Simplified Chinese, Russian, Polish) (*3) Notes: *1: During fast network browsing, the AVR GUI and Remote App display may be temporarily out of sync. *2: An HDMI connection between the AVR and Blu-ray player (HDMI Control setting = ON for both AVR and Blu-ray player) is required. *3: The OS language setting is automatically detected; when not available, English is selected. Compatible network models: 2015 Models: Network AV Receiver SR7010, SR6010, SR5010, NR1606, NR1506 Network AV Pre-Amplifier AV8802(A) 2014 Models: Network AV Receiver SR7009, SR6009, SR5009, NR1605 Network AV Pre-Amplifier AV7702 Network Audio Player NA8005 2013 Models: Network AV Receiver SR7008, SR6008, SR5008, NR1604, NR1504 Network CD Receiver Melody Media (M-CR610) Network Receiver Melody Stream (M-CR510) Network Audio Player NA-11S12012 Models: Network AV Receiver SR7007, SR6007, SR5007, NR1603 Network AV Pre Tuner AV8801, AV7701 Previous Models: Network AV Receiver SR7005, SR6006, SR5006, NR1602 Network AV Pre Tuner AV7005 Network Audio Player NA7004 Network CD Receiver M-CR603 Notes: *may require an online firmware update for the use of this application. Please check a latest firmware by following each User manual. *Please set "Network Standby / IP Control / Network / Network Control" to "On / Always On" in your Marantz product's menu to use this app. *If the App doesn't work well, please try to reboot your mobile device, unplug the power cord of the main unit and reinsert into the power outlet or check your home network. If the indicators are incorrect or the unit cannot be operated, restarting the unit may improve the problem. We recommend restarting the unit before returning the settings to the default settings. Link If the operations are not improved by restarting the unit, follow the steps below. Various settings are reset to the factory default values. Make settings again. Turn off the power using . Press while simultaneously pressing TUNER PRESET CH + and ZONE2 SOURCE. Remove your fingers from the two buttons when "Initialized" appears on the display. Before returning the settings to the default settings, use the "Save & Load" function from the menu to save and restore the details of various settings configured on the unit. link You can also reset all settings to the factory defaults using "Reset" - "All Settings" in the menu. link back to top There are a few ways to do this, but all newer AV and AVR models have a Factory Reset option listed in the menu (GUI) under General -> Factory Reset. From this menu, you can reset all saved settings or just your network settings. We highly recommend you save your settings to a USB drive before factory resetting the unit. To do that, place a supported USB drive into the unit's USB port. Then, access the menu (GUI) and select General -> Save/Load. This will save all altered settings including your Audyssey calibration. Once that's done, you can safely reset the unit. Another option to reset the unit's microprocessor would be to follow the push button reset procedure found in your model's owner's manual. Please see your owner's manual for this procedure as every model has a different push button procedure.