

Click to prove
you're human



In this post, we will discuss the methods to clear the Bluetooth memory on the Pioneer car radio. Also, you'll find how to connect, disconnect, or delete phones from units. Pioneer AVH-120BT (or similar) – Double DIN We are taking Pioneer AVH-120BT as an example of these options. Although most Pioneer touchscreen units will have similar steps, please refer to your manual for the exact steps if this doesn't work. Clear Bluetooth memory on Pioneer AVH (touchscreen unit) Step 1: Press the Power/Menu button Step 2: Touch the Wheel icon on the screen and then the Bluetooth icon Step 3: Find the menu item [Bluetooth Memory Clear]. Step 4: Touch [Clear] then [Ok] to clear the Bluetooth memory. How to connect, disconnect, or delete phones from Pioneer Bluetooth radio Step 1: Press the Power/Menu button Step 2: Touch the Wheel icon on the screen and then the Bluetooth icon Step 3: Find menu item [Connection]. Step 4: Select the option you need DELETE: To delete the registered device touch the Bin icon. CONNECT: To connect a device manually touch the name of the device. DISCONNECT: to disconnect a device touch the name of the device. How to change PIN code for Bluetooth connection Step 1: Press the Power/Menu button Step 2: Touch the Wheel icon on the screen and then the Bluetooth icon Step 3: Find the menu item [PIN Code Input]. Step 4: Touch 0 to 9 numbers to input the pin code (up to 8 digits). The default PIN code is "0000". How to Auto Connect devices Step 1: Press the Power/Menu button Step 2: Touch the Wheel icon on the screen and then the Bluetooth icon Step 3: Find the menu item [Auto Connect] and select [On] to connect the last connected Bluetooth device automatically. TIP: It automatically connects two Bluetooth devices that have been connected the last time in the order that they were registered. Resource: Pioneer AVH-120BT manual Pioneer DEH-S6220BS (or similar) – Single DIN With these steps, you can clear the Bluetooth device data (device list, PIN code, call history, phone book, preset phone numbers) stored in the unit. Pioneer DEH-S6220BS Step 1: Press the M.C. (multi-control) dial to display the main menu Step 2: Turn the M.C. dial to [SYSTEM settings], then press to confirm. Step 3: Find menu item [BT MEM CLEAR] Step 4: Set to [YES], then press to confirm. [CLEARED] appears when data is successfully deleted. Resource: DEH-S6220BS manual If you are unable to clear the Bluetooth memory on your Pioneer car radio using the above method, you should reset the entire unit. The system reset will automatically clear the Bluetooth memory of the unit as well. Do you want to Delete Phones Off of Pioneer Bluetooth Radio DivX? Bluetooth connectivity is a feature of this modern head unit which lets you stream music from your smartphone and do hands-free calling. Well, for this purpose, you just have to pair your smartphone with the head unit once and set the head unit to auto-connect. This setting lets you connect with your smartphone immediately. So, the number of devices that you want to pair with your head unit is limited. But after hitting that limit, it would not pair up with a new phone. And after that, you can get the 'BT memory full' error. Now, you have to adopt any solution for this error to delete some already-paired devices or you have to clear the Bluetooth memory. Well, if you want to learn how to delete phones off of Pioneer Bluetooth Radio DivX. So in this post, we'll discuss simple solutions. So let's get started for more detail! First of all, you have to Press the SRC button to turn on the radio. After that, you have to Rotate the multi-purpose dial until the SYSTEM SETTINGS option appears on the screen. After that, you have to rotate the dial Again until there is the BT MEM CLEAR option on your phone's screen. Here, you have to Set this option to YES and press the dial. A few moments later, it will start the Bluetooth memory clearance memory, and you will see the word CLEARED that appears on the screen. The Clear word means that the process has been completed. Well, there are two simple ways to go to Bluetooth settings in AVH-X2800BS. These ways are given below: You can click on the icon of gear on the home screen and you can go to Bluetooth settings by touching the Bluetooth icon. Or you can click on the gear icon in the telephone settings and you can go to Bluetooth settings by touching the Bluetooth icon. Well, here you have to engage the parking brake beforehand while the Bluetooth icon will be unresponsive, and you can not be able to access those settings. When you are in the Bluetooth settings area, you can see different kinds of options like Connection, Auto-Connect, and Phone Book Auto Synchronize, etc. You can see The second last of those options will appear, that is Bluetooth Memory Clear. So just Go to that option, and it opens a list of all the devices that have already paired with your Pioneer head unit. Here, you have to Touch the Clear Button to delete that list and clear all the Bluetooth memory for new phones. Finally, you have deleted Bluetooth memory. The Pioneer AVH head units also let you delete Bluetooth Radio DivX devices individually. It is so useful if you only delete a particular Bluetooth-paired device. So here is how to do this: First of all, you have to Touch the gear icon on the home screen. After that, you will see a new menu on your screen. From that menu list, you have to touch the Bluetooth icon. After opening Bluetooth Settings, you can click the Connection option. Here, you will see a list of the last three phones you paired with this head unit. Now, you can Touch the trash bin icon next to the phone that you need to delete. It will help you to delete that device, and you will be able to pair a new smartphone with your head unit now. So, if you have paired Pioneer Bluetooth Radio DivX and now you want to delete Bluetooth-paired devices from your Pioneer Bluetooth Radio DivX, then you can follow the above-mentioned easy processes. But if you face a bug and you can't be able to follow the above methods for some issues then you have only one solution which is resetting your pioneer radio. So that's all you need to know about How to Delete Phones Off of Pioneer Bluetooth Radio DivX? we hope this article will help you a lot! August 20, 2023 April 3, 2024 February 5, 2023 You can remove a phone from your Pioneer car audio system by performing the following steps: Step 1: Tap the phone connection icon on the Pioneer Radio touch screen. 2. Click the settings icon. Touch the letter "Connections" to access the list of connected phones in step 3. * Step 4: The screen will display a list of all the audio system-connected devices. To remove a device from your Bluetooth stereo, touch the trash can icon located next to it. How to delete phones off of pioneer bluetooth radio divx - (Image Source: Pixabay.com) How do I take a Bluetooth gadget out of my car radio? Select Bluetooth from the phone's settings. With the engine running, use the touch screen of the car to access the list of connected devices. Then, delete and reconnect your phone. Select the name of the phone. The Delete button Verify the phone's removal from the list of paired devices. Eliminate your phone from the list of connected devices in your car. 1. Use the touch screen of the vehicle to access the list of paired devices while the engine is running. 2. Choose the phone number. 3. Choose Delete. 4. Make sure the name of the phone is no longer listed among the paired devices. Eliminate the car from the list of paired devices on your phone. How to delete phones off of pioneer bluetooth radio mixtrax - (Image Source: Pixabay.com) How can I unpair an old Bluetooth device? Mobile devices running Android (smartphones, tablets) Swipe up from the bottom of the screen. Select the Settings icon. Choose Device Connection or Connected Devices. Select Bluetooth or previously connected devices. Turn on Bluetooth if it is currently off. dot. The should be tapped. dot Press the "Forget" button. How to delete bluetooth device from pioneer dmb-220ex - (Image Source: Pixabay.com) How do I get rid of unused Bluetooth devices? Using an Android smartphone or tablet, swipe up from the bottom of the screen. Click the Settings button. Choose Device Connection or Connected Devices. Select Bluetooth or previously connected devices. You should activate Bluetooth if it isn't already. dot. You can by tapping the dot. Press the "Forget" button. How to delete bluetooth device from pioneer avh-120bt without parking brake - (Image Source: Pixabay.com) How can all Bluetooth-paired devices be unpaired? To do this on an Android device, tap Apps after opening Settings. Select Show system apps after selecting the Sort icon (the downward-pointing arrow with three vertical bars). All of the system apps will show up in the list after you click OK. Tap Bluetooth > Storage > Clear Data. To confirm, press the OK button. Problems with disconnecting might be resolved by deleting the cache files on your Android device. To completely reset Bluetooth, you can clear the data cache on the phone or tablet; this is safe for both your device and your computer. Please take note that iOS devices cannot delete cache files. On your Android device, you must turn on system apps before clearing the cache. On an Android device, follow these instructions: Pioneer avh-120bt bluetooth memory full - (Image Source: Pixabay.com) How can I erase the Bluetooth memory on my phone? Clear the Bluetooth Cache on Your Android Device Open Settings, then select Apps. Select Show system apps after selecting the Sort icon (the downward-pointing arrow with three vertical bars). All of the system apps will show up in the list after you tap OK. Bluetooth > Storage > Clear Data can be tapped. To confirm, click OK. Cache files on your Android device may be removed to resolve disconnections. To completely reset Bluetooth, you can clear the data cache on the phone or tablet; this is safe for both your device and your computer. Removing cache files from iOS devices is not possible. You must turn on system apps on your Android device before clearing the cache. Using an Android device, you can do this by: How to delete bluetooth device from pioneer avh-501ex - (Image Source: Pixabay.com) Why do other devices keep appearing on my Bluetooth? Turn Bluetooth off if you're wondering why you're seeing unidentified devices on it. In your Bluetooth profiles, delete (forget) the profiles. By deleting those profiles, you force Bluetooth to pair up again, even though it typically needs to be manually connected or paired to establish a connection. If you see this listed under "OTHER DEVICES," your phone is not connected to it. This merely suggests that there is another Bluetooth device out there that can be found. Two Bluetooth devices can communicate with one another after successful pairing. One or both of the devices must broadcast a Bluetooth signal that the other devices can detect and connect to in order for them to find and identify each other so they can communicate. Simple: switch off Bluetooth. Deleting or forgetting your Bluetooth profiles is as simple as doing so. By deleting those profiles, you force Bluetooth to pair up once more, even though it typically needs to be manually connected or paired to establish a connection. Turn off or disable Bluetooth on any Bluetooth-enabled devices you may have, such as speakers or a phone. Pioneer avh bluetooth memory full - (Image Source: Pixabay.com) Why am I unable to remove a Bluetooth device from my list? If you're having trouble removing a Bluetooth device, it's possible that Windows won't "let go" of the device because it believes there is an active Bluetooth connection. To resolve this, turn off Bluetooth. Open Settings in Windows 11 and select Bluetooth and devices to correct that. Next, swipe the button to the left to deactivate Bluetooth. Although leaving Bluetooth devices paired to your computer typically has no drawbacks, you might occasionally want to clear out your Bluetooth settings by deleting devices you no longer use. Unused Bluetooth devices can usually be deleted without difficulty, but occasionally Windows develops a bug and the deletion of the device is unsuccessful. You can use the common and simple troubleshooting steps listed below to fix this issue and get your unwanted devices taken away. Starting by double-checking the most typical method, using Bluetooth settings, is the best way to uninstall Bluetooth devices from Windows 10 or Windows 11. How to delete bluetooth device from pioneer avh-210ex - (Image Source: Pixabay.com) How do I remove Bluetooth devices that I no longer want? Using an Android smartphone or tablet, swipe up from the bottom of the screen. Select the Settings icon. Choose Device Connection or Connected Devices. Select Bluetooth or previously connected devices. Turn on Bluetooth if it's not already. Click the dot. Press the "Forget" button. How do I remove Bluetooth-enabled phones from a Pioneer radio? Therefore, we simply return to that location, look at the phone you wish to delete, and click the trash can next to it. How do I delete Bluetooth data from my Pioneer radio? Bluetooth will not function if you click it, so you must click it off. After that, select the menu, not memory, once more. How do I remove unwanted Bluetooth devices? Swipe up from the bottom of the screen on an Android (smartphone or tablet) device. Choosing (Settings). Choose Device Connection or Connected Devices. Choose Bluetooth or previously connected devices. If you want to unpair a device, click Settings next to its name. Go to FORGET. For instructions on how to erase Bluetooth device information, choose the device type from the list below. For more information, consult the device's manual or get in touch with the manufacturer. Note: Depending on the OS version, the method may vary. Share your insights and solutions with other Sony customers by visiting our community. Find information about your product and get immediate notifications so you never again miss an update. Only the United Arab Emirates, Saudi Arabia, and Pakistan are currently supported. How do I remove a paired device from the Bluetooth Memory Clear option. After selecting that, all the paired devices will be deleted promptly. And if you want to delete any specific device, just tap on the name of that device, and you will be done in seconds!! The devices are deleted, you will see a confirmation message on the screen. Select okay, and then you can get out of that area without any issue. If your Pioneer car radio is connected with many devices, you may fail to add new ones. Therefore, it is quite important to know how to delete Bluetooth device from Pioneer radio. Well, the procedure is super simple; you will need only a few minutes. If you perform this technique one time, you can do it effortlessly for the rest of your life. Related Problem Solving Guide for Pioneer users: Things To Do When Your Pioneer Car Stereo Has No Sound How To Set the Clock On A Pioneer Car Stereo How To Reset Pioneer Car Stereo How To Connect Bluetooth To Pioneer Car Stereo How To Remove Pioneer Car Stereo Without Keys Removing a paired phone from your Pioneer Bluetooth radio is a straightforward process that can be accomplished in just a few simple steps. Whether you're looking to clear the device list for security reasons or to make room for new connections, it's essential to know how to delete a paired phone from your Pioneer radio. Here's a step-by-step guide to help you through the process: Access the Bluetooth Settings: Begin by accessing the Bluetooth settings on your Pioneer radio. This can typically be done by navigating to the Bluetooth menu on the radio interface. Once in the Bluetooth settings, locate the option for "Paired Devices" or "Device List." Select the Paired Phone: Within the list of paired devices, locate the phone that you want to remove. Select the option to delete or forget the device. Confirm the Deletion: After selecting the "Delete" or "Forget" option, the radio may prompt you to confirm the deletion. This serves as a final confirmation to ensure that you want to remove the selected device from the paired list. Confirm the action to complete the process. Verify Removal: To ensure that the paired phone has been successfully deleted, check the device list again. The phone you removed should no longer appear in the list of paired devices. By following these simple steps, you can easily delete a paired phone from your Pioneer Bluetooth radio. This process allows you to manage your connected devices efficiently and maintain the security and functionality of your Pioneer radio system. Remember, the exact steps may vary slightly depending on the model of your Pioneer radio, so it's always a good idea to refer to the user manual for specific instructions tailored to your device. Step-by-Step Guide to Removing a Phone from Pioneer Radio Removing a phone from your Pioneer radio's list of paired devices is a simple process that can be completed with just a few straightforward steps. Whether you're clearing out old connections to make room for new ones or ensuring the security of your Bluetooth network, knowing how to remove a phone from your Pioneer radio is essential. Here's a detailed guide to walk you through the process: Access the Bluetooth Settings: Begin by accessing the Bluetooth settings on your Pioneer radio. This can usually be done by navigating to the Bluetooth menu on the radio interface. Look for options such as "Paired Devices" or "Device List." Identify the Phone to Remove: Within the list of paired devices, locate the phone that you want to delete. Pioneer radios typically display the names of the paired devices, making it easy to identify the one you wish to remove. Initiate the Removal Process: Once you've located the device you want to remove, select it from the list. Depending on your Pioneer radio model, there may be an option to "Delete" or "Forget" the device. Choose this option to initiate the removal process. Confirm the Deletion: After selecting the "Delete" or "Forget" option, the radio may prompt you to confirm the deletion. This serves as a final confirmation to ensure that you want to remove the selected device from the paired list. Confirm the action to proceed. Verify Cleared Devices: To ensure that the paired devices have been successfully cleared, review the device list again. The devices you removed should no longer appear in the list of paired devices, indicating that the clearing process was successful. By following these steps, you can effectively clear paired devices from your Pioneer Bluetooth radio, allowing you to manage your connected devices efficiently and maintain the security and functionality of your audio system. Keep in mind that the exact steps may vary slightly depending on the model of your Pioneer radio, so it's advisable to consult the user manual for specific instructions tailored to your device. Tips for Deleting Phones from Pioneer Radio When it comes to deleting phones from your Pioneer radio, a few tips can streamline the process and ensure that you can efficiently manage your paired devices. Here are some valuable tips to consider when removing phones from your Pioneer radio: Review the User Manual: Before attempting to delete paired phones from your Pioneer radio, it's beneficial to review the user manual for your specific radio model. The manual can provide model-specific instructions and tips tailored to your device, ensuring that you follow the correct steps for deleting paired phones. Verify Bluetooth Connectivity: Before initiating the deletion process, ensure that your Pioneer radio is connected to the Bluetooth device management interface. This ensures that you can efficiently navigate the menu and access the options for deleting paired phones. Double-Check the Selection: When selecting a phone for deletion, double-check to ensure that you've chosen the correct device from the paired list. Verifying the selection can prevent accidental removal of the wrong device. Confirm Deletion Prompts: Pay close attention to any confirmation prompts that appear during the deletion process. Confirming the deletion is a crucial step to ensure that the selected phone is removed from the paired list. Ensure Successful Removal: After deleting a paired phone, verify that the device no longer appears in the list of paired devices on your Pioneer radio. This confirms that the removal process was successful. By keeping these tips in mind, you can effectively navigate the process of deleting phones from your Pioneer radio. These tips are designed to help you manage your paired devices efficiently and maintain the security and functionality of your Pioneer radio system. Remember, each Pioneer radio model may have specific nuances in the deletion process, so consulting the user manual for detailed instructions is always advisable. Common Issues and Troubleshooting for Removing Phones from Pioneer Bluetooth Radio While removing phones from your Pioneer Bluetooth radio is typically a straightforward process, certain issues may arise that can hinder the deletion of paired devices. Understanding common issues and troubleshooting methods can help you navigate potential challenges effectively. Here are some common issues and troubleshooting tips for removing phones from your Pioneer Bluetooth radio: Difficulty Accessing Bluetooth Menu: If you encounter difficulty accessing the Bluetooth menu on your Pioneer radio, ensure that the radio is not in a mode that restricts access to device management settings. Switch to a mode that allows access to Bluetooth settings, such as the radio or auxiliary mode. Unresponsive Deletion Option: In some cases, the deletion option for paired devices may be unresponsive. If this occurs, try restarting the Pioneer radio and accessing the Bluetooth menu again. If the issue persists, consult the user manual for alternative methods of removing paired devices. Device Not Found in Paired List: If a device you want to remove does not appear in the paired list, ensure that the device is within range and its Bluetooth functionality is active. Additionally, verify that the device is not currently connected to the Pioneer radio, as connected devices may not appear in the paired list. Confirmation Prompts Not Displayed: If confirmation prompts for deletion do not appear after selecting the deletion option, check the radio's display settings to ensure that prompts are not disabled or hidden. If prompts are still not displayed, consult the user manual for alternative confirmation methods. Pairing Limitations: Some Pioneer radio models may have limitations on the number of devices that can be paired simultaneously. If you encounter difficulties removing a device due to pairing limitations, consult the user manual for guidance on managing paired devices within the specified limits. By familiarizing yourself with these common issues and troubleshooting tips, you can address potential challenges when removing phones from your Pioneer Bluetooth radio. Troubleshooting methods may vary depending on the specific model of your Pioneer radio, so referring to the user manual for model-specific guidance is recommended. Successfully navigating these common issues ensures that you can efficiently manage your paired devices and maintain the functionality and security of your Pioneer Bluetooth radio system. (Many of the links in this article redirect to a specific reviewed product. Your purchase of these products through affiliate links helps to generate commission for AudioLover.com, at no extra cost. Learn more) Bluetooth technology has revolutionized how we connect our devices, including smartphones, to various electronic devices, such as car radios. One popular brand known for its Bluetooth-enabled car radios is Pioneer. If you have a Pioneer Bluetooth radio and find that you need to delete phones from its pairing list, you've come to the right place. In this article, we will guide you through the step-by-step process of deleting phones off of a Pioneer Bluetooth radio. Deleting unwanted phones can be essential if, for example, you have recently sold your car or if you have multiple phones that have been registered on the radio and you no longer want them to appear in the list of available devices. By removing these phones, you can ensure that only the desired devices are connected and minimize any potential disruption during your driving experience. Remember, different Pioneer models may have slightly different user interfaces, so it's always a good idea to consult your specific radio's user manual for precise instructions. However, the general steps outlined in this guide should help you delete phones from most Pioneer Bluetooth radios. Now, let's dive into the process of deleting phones off of a Pioneer Bluetooth radio in the following sections. The first step in deleting phones from your Pioneer Bluetooth radio is to access the Bluetooth settings. To do this, you will need to navigate through the radio's menu options. Here's how: Start by turning on your Pioneer Bluetooth radio. Ensure that it is powered and in Bluetooth mode. Next, locate and press the "Menu" or "Settings" button on the front panel of the radio. This button may be labeled differently depending on the model of your Pioneer radio. Once you've entered the menu or settings screen, use the control dial or arrow buttons to navigate through the options. Look for the Bluetooth settings or connectivity section. Select the Bluetooth settings option to access the list of paired devices. This is where you will find the phones that are currently registered with your Pioneer radio. By following these steps, you should now be able to access the Bluetooth settings on your Pioneer radio. Now, let's move on to the next step, where we'll show you how to select the paired phones for deletion. Now that you've accessed the Bluetooth settings on your Pioneer radio, it's time to select the phones you want to delete from the list of paired devices. Here's how you can do it: Navigate to the Bluetooth settings menu using the control dial or arrow buttons on your radio. Look for the option that displays the list of paired devices. It may be labeled as "Paired Phones" or "Registered Devices." Select this option to open the list. You should now see a list of the phones that are currently connected or have been previously paired with your Pioneer Bluetooth radio. Use the control dial or arrow buttons to scroll through the list and locate the phone(s) you want to delete. Pioneer radios usually display the phone's name or a unique identifier, such as "Phone 1" or "Device A." Once you have located the phone(s) you want to remove, make note of their name(s) to ensure you select the correct ones in the next step. Now, let's move on to the next step, where we will show you how to delete a phone from your Pioneer Bluetooth radio. Now that you have selected the phone(s) you want to delete from your Pioneer Bluetooth radio, it's time to proceed with the deletion process. Follow these steps: In the Bluetooth settings menu on your Pioneer radio, locate the phone you want to delete from the list of paired devices. Select the phone by highlighting it using the control dial or arrow buttons. Once the phone is highlighted, look for an option that allows you to delete or remove the selected device. This option may be labeled as "Delete," "Remove," or "Forget." Press the appropriate button or select the option to delete the phone. Depending on your Pioneer radio model, you may be prompted to confirm the deletion. If prompted, verify that you want to delete the selected phone from the Bluetooth pairing list. Once you have completed these steps, the selected phone will be deleted from your Pioneer Bluetooth radio's pairing list. Now, let's move on to the next step, where we will show you how to confirm the deletion. After deleting a phone from your Pioneer Bluetooth radio, it is essential to confirm that the deletion was successful. Here's how to do it: Return to the list of paired devices in the Bluetooth settings menu on your Pioneer radio. Verify that the phone you just deleted is no longer present in the list. It should no longer be displayed with its name or identifier. If the phone is still listed, try repeating the deletion process again to ensure it is removed completely. Once you have confirmed that the phone is no longer in the pairing list, exit the Bluetooth settings menu and return to the main screen of your Pioneer radio. If you have multiple phones to delete, you can repeat steps 3 and 4 for each device until all unwanted phones have been removed. By confirming the successful deletion of the phone(s) from your Pioneer Bluetooth radio, you can ensure that only the desired devices are connected and available for use. Now, let's move on to the last step, where we will discuss how to repeat the process for multiple phones. If you have multiple phones that you want to delete from your Pioneer Bluetooth radio, you can easily repeat the deletion process for each device. Here's how: Once you have confirmed the deletion of a phone, return to the list of paired devices in the Bluetooth settings menu on your Pioneer radio. Select the next phone you want to delete by highlighting it using the control dial or arrow buttons. Follow the same steps outlined in Step 3: Deleting a Phone from the Pioneer Bluetooth Radio and Step 4: Confirming the Deletion to delete and confirm the removal of the additional phones. Repeat this process for each phone you want to delete until all unwanted devices have been removed from the pairing list. By following these steps, you can efficiently delete multiple phones from your Pioneer Bluetooth radio. Once you have finished deleting all the desired devices, you can be confident that only the necessary phones are connected to your radio. Now, let's conclude our guide on how to delete phones off of a Pioneer Bluetooth radio. Deleting phones from your Pioneer Bluetooth radio is a straightforward process that can help you maintain a tidy and organized list of paired devices. By following the steps outlined in this guide, you can easily remove unwanted phones from your radio's pairing list. Remember, it's important to access the Bluetooth settings on your Pioneer radio and select the paired phones you want to delete. Confirm the deletion and ensure that the removed phones are no longer listed in the pairing menu. If you have multiple phones to delete, repeat the process for each device until all unwanted phones have been removed. By keeping your list of paired devices up to date, you can ensure a smoother and more efficient Bluetooth connectivity experience in your car. Removing unnecessary phones also minimizes any potential interference or confusion when trying to connect your desired device. As always, be sure to consult your Pioneer radio's user manual for any model-specific instructions, as the exact steps may vary slightly. We hope this guide has been helpful in showing you how to delete phones off of a Pioneer Bluetooth radio. Enjoy your Bluetooth connections with ease and enjoy a seamless driving experience!